





4832L Parts List



Right Shelf Side (1) Left Shelf Side (1)



Shelf (3) Back Panel (2)


Hardware Pack

(a) Qty 12 - 1/4"-20 x 3/8" Pan Head Screw	
(r) Qty 8 - 1/4"-20 x 5/16" Pan Head Screw with Locktite	

4832L Assembly Instructions

Step 1


- Lay “Shelf Side” on its side with inside of support facing up as shown.
- Attach shelves in desired locations and orientations with the threaded side facing forward.
- NOTE: Ram ProMaster City you may not want to use the lowest location to optimize aisle width (up 1 location will give better wheel well clearance, lower “Back Panel” will also need to be removed).
- Tap with a hammer to ensure a snug fit.



Step 2

- Attach other “Shelf Side” on top of shelves.
- Bolt shelves to shelf side using $\frac{1}{4}$ ”x $\frac{3}{8}$ ” screw (a) at the front and back of the shelf. Each shelf should use 4 screws to properly secure onto shelf sides.


TIGHTEN



Step 3

- Attach both “Back Panels” using ¼”x 5/16” screws (r) as shown, NOTE: use the screws with the locking tabs on the bottom of the head.

HAND TIGHTEN ONLY



- Stand shelving unit upright and check for square.

TIGHTEN

**Check for rattling

